


Special Features

Digital Effects

1. Push the digital effects button, which is located on the side of the LCD screen.



2. Scroll through the choices by sliding the wheel (which has a volume sign) up or down.



3. Select "Effect" by pushing the center of the navigation wheel.
4. Scroll to the desired effect.
5. Push down on the navigation wheel again.
6. Push the digital effects button.
7. Push the On/Off button, until the desired effect appears.



Produced in partnership with
Luther Jackson Middle School



Sabrina Castellanos

&

Allison Stafford

2005

Fairfax County Public Schools

Department of
Information
Technology

THE CANON ZR 40 VIDEO CAMERA



TMPC
Loan Pool
703-503-7430

Getting Ready to Use the Camera


1. Insert the battery by putting the bottom in first, make sure you hear a click to know the battery is securely in place.
2. To turn the camera on, rotate the gray dial, which encircles the red button, to the word "camera."



3. Place the cassette in the bottom of the camera. Slide the eject button to the right.



4. To close it, carefully push the top down without forcing it. The door will automatically close.



Getting Ready to Use the Camera (Cont.)

5. Make sure that the lens cap is off. To take it off squeeze both sides of the cap.
6. slide the open button towards you to open the LCD screen.



7. To start recording push the red button.
8. To pause the recording, press the red button again.
9. To view what you have recorded, rotate the gray dial, which encircles the red button, to the word "play(VCR)."
10. To remove the cassette from the video camera, repeat steps 3 and 4.
11. To turn the power off, rotate the gray dial, which encircles the red button, to the word "Off."



Special Features

Photo

To take a photo, push the photo button, located at the top right of the camera, next to the zoom button.



Zoom

To zoom, slide the button that says W-T to the desired position. To zoom in, slide to the right toward the "T". To zoom out, slide to the left toward the "W."

